
12-1025 / 12-1025HR

DASELINE® EVALUATION INSTRUMENTS

ABSOLUTE+AXIS™ GONIOMETER



A New Improvement In Goniometry - HORIZONTAL AND VERTICAL LEVELS Finally...No More Guesswork!


Many goniometric measurements require the practitioner to place one arm of the goniometer in either the horizontal or vertical position. The other arm is then lined-up with the patient's body segment.

Until now, the practitioner had to "assume" or "eyeball" the vertical or horizontal position. This interpretation of horizontal or vertical is often incorrect and allows for measurement error. The Absolute+Axis (**AA**) goniometer removes the "assume" and "eyeball" by establishing a "true" vertical or horizontal. The Absolute+Axis goniometer removes measurement variability and allows the practitioner to concentrate on correct placement of the other goniometer arm and the patient's body position.

Some measurements the **AA** goniometer is designed to improve are: shoulder and hip rotation (internal, external);

cervical flexion, extension, rotation and side bending; hamstring flexibility;

and active ROM.



Available on 12-1025 and 12-1025HR, "built-in levels" take away guesswork regarding absolute horizontal or vertical positions

BASELINE® HiRes™ Diagnostic and Measuring Instrumen



Fabrication
Enterprises
Incorporated


Manufacturer and Master Distributor of
Physical Therapy and Rehabilitation Products

Fabrication Enterprises, Inc. PO Box 1500 White Plains, New York 10602 USA


tel: 800-431-2830 914-345-9300 fax: 800-634-5370 914-345-9800 info@FabricationEnterprises.com

Absolute+Axis™ Attachment (12-1026) for 12" Plastic Goniometers 12-1000 and 12-1000HR


Perfect for those practitioners who currently own a 12" 360° plastic goniometer. Attachment slides "snugly" onto one arm of the goniometer providing the accuracy of a true **Absolute+Axis™** and does not interfere with the goniometer's function.



TO CONVERT EXISTING GONIOMETER INTO AN ABSOLUTE+AXIS™,
SLIDE PART #12-1026 OVER GONIOMETER ARM UNTIL IT LOCKS IN PLACE



UPDATED GONIOMETER WITH ABSOLUTE+AXIS™ ACCURACY



Make sure "bubble" on level is centered. This makes rotation measurement accurate.













shoulder external rotation



elbow external rotation



DASELINE EVALUATION INSTRUMENTS

www.BaselineProducts.net

The Most Extensive Instrument Range for Measuring Progress in Physical Therapy

- Baseline Measure strength, range-of-motion, and more
- Baseline Lightweight and portable
- Baseline Inexpensive and cost effective
- Baseline Accepted by physical and occupational therapists for over 25 years



wrist dynamometer



back-leg-chest dynamometer



pinch geriges



la tible inclinameter



heavy) executed on set



baylor haraners



granitamieters



wrist indinometers

For complete line of Baseline products, see pages 56-87 in the 2008 FEI catalog or view online at www.FabricationEnterorises.com